



IP Modulator User Manual

Model: SKD710X

***The X in the model number stands for different output modulations.**



Dingshengwei Electronics Co., Ltd.

The final interpretation right of this document belongs to our company

Preface

First of all, thank you for choosing our products.

This manual details the performance, installation and operation of the product.

Please read this manual before use. Our company, Shenzhen Dingshengwei Electronics Co., Ltd., does not assume any responsibility for any losses caused by violations of safety regulations.

1. Incoming inspection

(1)Open the equipment box and check the contents against the product packing list.

(2)If the packing list does not match the actual items, please contact us.

2. Read the instruction manual

Please read the instructions and follow all instructions.

(1)Power supply

The power supply used with this device must comply with the indicated power supply and be grounded. When not using the machine for a long time, please unplug the power cord

(2)Working environment

Keep the equipment working in a ventilated and dry place. Avoid excessive heat, moisture, dust and heat

(3)Equipment cleaning

Before cleaning the device, unplug the power cord. Do not use liquid or spray cleaners.

(4)Power cable protection

Pay special attention to the safety protection of plugs, sockets and power cords

(5)Overload

Be careful not to overload the power supply at the outlet. Use caution when using extension cords or integrated sockets as this may result in electric shock and fire.

(6)Lightning

To prevent damage caused by lightning, please use this device in a lightning protection device, which can effectively prevent damage caused by lightning or power grid fluctuations.

(7)Foreign matter or liquid intrusion

Do not insert foreign objects into the machine or spill any liquid into the machine.

(8)Appendix

Do not use accessories not recommended by the manufacturer, as this may cause danger.

(9)Transportation

When transporting the machine, the original packaging of the product should be used to avoid damage. Do not place heavy objects on the machine or step on it.

Otherwise, personal injury may occur and the machine may be damaged.

(10)maintain

Do not open the box and repair by yourself to avoid personal injury or serious damage to the machine.

During the warranty period, if the product is damaged due to natural causes and is disassembled without authorization, free warranty will not be provided.

Content

Preface	2
1. Product description	1
1.1. Product overview	1
1.2. Photo	1
1.3. Features	1
1.4. Application scenarios	2
1.5. Parameter	2
2. Structure diagram	10
2.1. Front panel	10
2.2. Rear panel	11
3. Installation guide	11
3.1. Preparation	11
3.2. Device installation process	12
3.3. Environmental conditions requirements	12
3.4. Grounding requirements	14
4. Built-in web management terminal operation	15
4.1. Preparation before operation	15
4.2. Login interface	15

4.3. Device status.....	16
4.4. IP input.....	17
4.5. Router	20
4.6. Output.....	27
4.6.1. Channel list.....	27
4.6.2. RF settings.....	28
4.7. System.....	32
4.7.1. Basic parameters	32
4.7.2. Network.....	34
4.7.3. Account.....	34
4.7.4. System.....	35
4.7.5. Time And Date	36
4.7.6. COULD	36
5. Equipment operation precautions.....	38
5.1. Precautions	38
5.2. The chassis needs to be unplugged from the power supply	39
5.3. Common malfunctions.....	39

2. Product description

2.1. Product overview

SKD710X is a platform product for centralized processing of small digital TV front-end services. The installation method is flexible and can be installed in cabinet, wall-mounted, or desktop.

Parameters can be configured through local operating equipment. The WEB page is beautiful and easy to understand, simple to operate, and has intelligent functions such as batch import and export of parameters. It is a highly integrated and cost-effective digital TV front-end signal comprehensive processing equipment.

2.2. Photo



2.3. Features

- Support UDP/RTP protocol input, support SPTS/MPTS stream processing
- Support 256 IP addresses, Gigabit input
- Supports PID remapping, PSI/SI information editing and insertion

- Supports digital modulation output of 4/8 frequencies, and the output modulation supports DVBC (J83A/C), DVB-T/T2, DTMB, ISDB-T, ATSC, QAM (optional)
- 1 Gigabit port and 1 management port
- Operated through PC (WEB)

2.4. Application scenarios

- Business travel hotel
- Clubhouse
- Hospital
- Spa
- School
- Leisure and entertainment clubs
- Prison

2.5. Parameter

SKD710X Base unit parameter	
Size	318(L)*260(W)*44(H)mm
Installation	1U 19 inch rack、 wall-mounted, desktop
Working temperature, humidity	-10°C-45°C、 40%-70%

Storage temperature and humidity	-40℃-70℃、40%-95%	
Power	Supply voltage	DC12V
	Maximum current	7000mA
IP Input	IP input port	1 Gigabit RJ45 network port
	Input format	Support UDP/RTP protocols input,support SPTS/MPTS stream processing , support 256 IP address
RF output	Output port	female connector , 1 RF output and 1 -20dB test port output
	Output standard	DVBC(J83A/B/C), DVBT/T2, DTMB, ISDB-T, QAM, ATSC(optional)
	RF frequency range	50-870MHz minimum step 1MHz
	Output level	≥105dBuV (0-20dB Adjust range , step 0.5dB)
	Out band rejection	≥60dB
	Output impedance	75Ω
	Output	4/8 frequencies (optional)

	frequencies	
--	--------------------	--

Modulation parameter		
J.83A/C	Standard	Annex A/C
	Frequencies	4
		8
	Constellation	16QAM、32QAM、64 QAM、128 QAM、256 QAM
	MER	≥36dB
	Symbol rate	3.600~6.960Msps
	Output frequency range(adjustable)	50-999.999MHz , minimum step 0.001MHz
	Output level	110dBuV±3dB
	Output level adjustment range	0 ~ -20dB
	Out band rejection	≥60dB
	Output impedance	75Ω
DTMB	Standard	GB20600-2006

	Frequencies	4
		8
	Constellation	QPSK, QAM16, QAM64, QAM4_NR, QAM32
	FFT	Single carrier, multi-carrier
	Sync Frame	420, 595 and 945
	Code Rate	0.4, 0.6, 0.8
	Interweaving depth	None, 240, 720
	MER	≥36dB
	Output frequency	50-999.999MHz , minimum step 0.001MHz
	Output level	110dBuV±3dB
	Output level adjustment range	0 ~ -20dB
	With out band rejection	≥60dB
	Output impedance	75Ω
ISDB-T	Standard	ANSI/SCTE 2001-B004
	Frequency	4
		8

	Constellation	QAM4, QAM16, QAM64
	FFT	2K, 4K, 8K
	Guard interval	1/4 , 1/8 , 1/16 , 1/32
	Code Rate	1/2 ,2/3,3/4,5/6 ,7/8
	Interweaving depth	None , 2k , 4k , 8k
	Bandwidth	6MHz
	MER	≥36dB
	Output frequency	50-999.999MHz , minimum step 0.001MHz
	Output level	110dBuV±3dB
	Output level adjustment range	0 ~ -20dB
	With out band rejection	≥60dB
	Output impedance	75Ω
DVB-T	Standard	ETS 300 744
	Frequency	4
		8
	Constellation	QAM4, QAM16, QAM64

	FFT	2K、 4K、 8K
	Guard interval	1/4 , 1/8 , 1/16 , 1/32
	Code Rate	1/2 ,2/3,3/4,5/6 ,7/8
	Interweaving depth	None , 2k , 4k , 8k
	Bandwidth	6MHz , 7MHz , 8MHz ,
	MER	≥36dB
	Output frequency	50-999.999MHz , minimum step 0.001MHz
	Output level	110dBuV±3dB
	Output level adjustment range	0 ~ -20dB
	With out band rejection	≥60dB
	Output impedance	75Ω
DVB-T2	Standard	EN 302 755
	Frequencies	4
		8
	Constellation	QAM4, QAM16, QAM64,QAM256
	FFT	2K、 2K、 4K、 8K、 16K

	Guard interval	1/4 , 1/8 , 1/16 , 1/32
	Code Rate	1/2 , 2/3, 3/4, 5/6 , 7/8
	Interweaving depth	Support all 3 Time Interleave options without sub-slicing and no frame jump.
	Bandwidth	1.7 , 6 , 7 , 8 , 10MHz
	MER	≥36dB
	Output frequency	50-999.999MHz , minimum step 0.001MHz
	Output level	110dBuV±3dB
	Output level adjustment range	0 ~ -20dB
	With out band rejection	≥60dB
	Output impedance	75Ω
ATSC	Standard	8VSB
	Frequencies	4
		8
	Bandwidth	6MHz
	MER	≥36dB
	Output	50-999.999MHz , minimum step 0.001MHz

	frequency	
	Output level	110dBuV±3dB
	Output level adjustment range	0 ~ -20dB
	With out band rejection	≥60dB
	Output impedance	75Ω
QAM	Standard	Annex B
	Frequencies	4
		8
	Constellation	64 QAM、 256 QAM
	Symbol rate	5.05641 MS/s(64 QAM) , 5.360537 MS/s (256 QAM)
	MER	≥36dB
	Output frequency adjustment range	50-999.999MHz , minimum step 0.001MHz
	Output level	110dBuV±3dB
	Output level	0 ~ -20dB

	adjustment range	
	With out band rejection	≥60dB
	Output impedance	75Ω

3. Structure diagram

3.1. Front panel



No.	Function	
1	PER	This indicator light lights up when the device is powered on
	RUN	This indicator light lights up when the device is running
2	DATA IN	Gigabit input network port
3	NMS	Management port
4	DUFAULT	Restore factory settings button. If you need to restore factory

		settings, you need to press and hold for 15 seconds.
--	--	--

3.2. Rear panel



No.	Function	
1	RF OUT	Signal output port, level does not attenuate
	TEST -20db	Test port, level signal attenuation 20db
2	switch	
3	power inlet	
4	ground	

4. Installation guide

4.1. Preparation

When installing the device, follow these steps:

- Check for possible loss or damage of equipment during transportation;
- Prepare a suitable environment for installation;
- Install the required input and output cables;

Each detail when installing the equipment will be described in the rest of this chapter.

The specific location can be found in the rear panel diagram..

4.2. Device installation process

Step 1:Unpacking and inspecting goods

Step 2:Fixed equipment

Step 3:Connect power and ground wires

Step 4:Connect signal cable

Step 5:Connect signal cable

Step 6:Set device parameters

Step 7:Set device parameters

Step 8:Equipment operation

4.3. Environmental conditions requirements

Project	Requirement
Control room space	When installing multiple rows of cabinets, the distance between the front and rear doors of the cabinet is 1.2~1.5m and the distance from the wall is 0.8m.
Control room floor	Non-conductive and dust-free. The volume resistivity of the ground anti-static material is $1 \times 10^7 \sim 1 \times 10^{10}$, and the grounding current limiting resistance is 1M. The floor load-bearing should be greater than 450Kg/m ² .

Ambient temperature	For long-term work in an environment of 5~40°C, and for short-term work in an environment of 0~45°C, it is best to install air conditioners in places to facilitate heat dissipation.
Relative humidity	Work long-term in the 20% to 95% environment and short-term in the 10% to 97% environment.
Ambient air pressure	86kPa~106kPa.
Windows	Dust-proof rubber strips must be added for sealing. It is recommended that windows be installed with double-glazing and strictly sealed.
Wall	Wallpaper can be applied or matte paint can be applied, but paint that is easily powdered should not be applied.
Fire protection requirements	The control room should be equipped with an automatic fire alarm system and a portable fixed fire extinguishing system.
Power requirements	Three independent power supply systems are required for equipment power supply, air conditioning power supply, and lighting power supply. The equipment is powered by AC power supply. The AC power supply adopts 220V±20% 50/60Hz. Please check carefully before operating the equipment.

4.4. Grounding requirements

- The good ground wire design of each functional module is the basis for the stable and reliable operation of the whole machine, and is the primary guarantee for lightning protection and anti-interference. Therefore, system grounding must follow the following principles;
- Both ends of the outer conductor and shielding layer of the coaxial cable should maintain good electrical contact with the outer surface of the metal chassis of the connected equipment;
- The ground conductor must use copper conductor to reduce high-frequency impedance, and the ground wire should be as thick and short as possible;
- The connection points at both ends of the grounding wire should be confirmed to have good electrical contact and should be treated with anti-corrosion;
- It is strictly prohibited to use other equipment as part of the electrical connection of the ground wire;
- The cross-sectional area of the ground wire connecting the cabinet to the lightning protection unit must be greater than or equal to 25mm^2 .
- Cabinet grounding: The ground terminals of each cabinet in the same computer room should be connected to the protective ground copper bar provided by the bureau. The grounding wire is required to be as short as possible. If the wiring is too long during project installation, it should be cut off to avoid coiling of the grounding wire. The cross-sectional area of the conductor from the ground terminal to the ground bar must be greater than or equal to 25mm^2 .


5. Built-in web management terminal operation

5.1. Preparation before operation

- The NMS network port of the device is connected to the PC network port;
- Power the equipment;

5.2. Login interface


- You can check the IP address of the device through the operation panel.
- Open IE browser/Firefox browser/Google Chrome/Opera browser/Maxthon browser, enter the device IP address in the address bar (generally default: 192.168.1.30), and after confirmation, the login interface will be displayed as follows:
- **Enter username and password, the default is: user**
- Click to log in



Notice:

1. If the connection cannot be made, please check whether the PC and the device are on the same network segment. If not, please add a new network segment in the advanced TCP/IP settings of the PC. For example: the PC's IP address is 192.168.99.252, which can be changed to 192.168.1.xxx (xxx can be any value from "1" to "254" except "252" to avoid IP conflicts).
2. If you still cannot connect after the above operations, or you forgot to log in to the IP address, please operate the front panel of the device to restore the factory default values.
3. If you need to change the language, please change it in the upper right corner of the page. Select ENGLISH/简体中文.

5.3. Device status




Serial Number	Display device serial number
Software	Display the current software version number of the device


Version	
Modulation	Displays the modulation system currently output by the device
Temperature	Display the temperature of the device's core board, and display the number of temperature progress bars based on the number of core boards.
Rear Panel	Gray color
Cooling Fans	Displays the operating status of the fans in the device. Under normal conditions, all fans will rotate. Blue: running; black: stopped; the fan stops running and a yellow triangle warning appears△
Front Panel	Displays the current access status of the front panel. Green: connected; gray: not connected
Language	简体中文/ENGLISH
User	Display the user name currently logged in to the device backend
Quit	Exit the device background management terminal
On Cloud State	Displays the binding status of the device on souka cloud. Green: bound; gray: unbound

5.4.IP input

The initial page is as shown below. We add the IP address of the program source by clicking the Add button.



Add IP address :



Add

☒ Unicast
☐ Multicast

From: ETH1

IP Address: 192.168.100.1

Port: 50000

Step Times: 1

Count: 1

Cancel Submit

Add

☐ Unicast
☒ Multicast

From: ETH1

IP Address:

Port: 50000

Step Mode: IP Address

Step Times: 1

Count: 1

Cancel Submit

Unicast

From

Default device network port

IP address	The default IP address is 192.168.100.1
Port	Default is 50000, can be modified, value range is 1-65535
Step times	Default 1, value range 1-10
Count	Default 1, value range 1-248
Submit	After filling it out, click the submit button.
Multicast	
From	Default device network port
IP address	Fill in the new IP address
Port	Fill in the port of the new IP address. Value range 1-65535
Step mode	IP address/port/IP address+port, three steps.
Step times	Range 1-10
Count	Range 1-248
Submit	After filling it out, click the submit button.

IP

+ Add

Delete

NO.		IP Address	Port	Bitrate(Kbps)
ETH1 (4/4)				
1	<input type="checkbox"/>	239.1.1.143	50000	4957.18
2	<input type="checkbox"/>	239.1.1.144	50000	9430.08
3	<input type="checkbox"/>	239.1.1.145	50000	9697.79
4	<input type="checkbox"/>	239.1.1.146	50000	9297.73

Total 4 data

100 Data/Page

<<

<

1


>

>>

Table Contents Explanation	
Up to 256 IP addresses can be added as long as they do not exceed the range	
NO.	Visually display the amount of table data. The check box next to it can select all table contents.
ETH1	Input network port display
IP address	Display and set IP address
Port	Display and set port number. Value range 1-65535
Bitrate	Display and update bitrate in real time
Page Button Explanation	
Delete	Single/batch deletion. Delete checked data.
Modifications to the table data will take effect.	

5.5. Router

In router management, we can analyze and forward programs.



RF1-RF8	The quantity of output channels is determined by the quantity of modulation cards, with a maximum of 8 channels supported.	
	Gray bar	Indicates a suitable bit rate range. When the bit rate of the forwarded program exceeds this range, the program may appear mosaic.
	Green bar	When a program is forwarded to a designated channel, the channel will identify the bit rate of the program and indicate it with a green bar.

The screenshot shows a web interface with a table of programs. The table has columns: NO., Type, Slot, Service Name, State, CA, RF Channel, PID Edit, and Action. There are four rows of programs. The first row is expanded, showing a 'Forward' button. The second row is collapsed. The third row is expanded, showing a 'Cancel' button. The fourth row is collapsed. At the bottom, there is a summary bar: 'Total 4 data', '100 Data/Page', and 'Total programs: 4', 'Forwarded programs: 2', 'Not forwarded programs: 2'.

NO.	Type	Slot	Service Name	State	CA	RF Channel	PID Edit	Action
1	IP	0-1	CCTV-5	●		Select a channel		Forward
2	IP	0-3	Soccer	●		RF1 (474.000)MHz		Cancel

Check	<p>You need to click the + sign firstly to expand the program before you can select the program.</p> <p>The all-select check box can only select all expanded programs. Programs that have not been expanded cannot be selected.</p>	
Cancel Forwarding	First check, then click the Cancel Forwarding button to cancel forwarding the program	
Quick Setting	Set RF channels for selected programs individually/batch	
Show	Type	Filter by the type of connected signal source.

	RF channel	Filter by radio frequency channel for program forwarding
NO.	<p>Represents: signal source slot-channel (quantity of forwarded programs/total quantity of programs)</p> <p>Click the "+" sign to expand and display the program list under the channel. The programs can be set, analyzed and forwarded;</p> <p>Click the "-" sign to close the program list;</p>	
Type	Display the input type of this program	
Slot	Display the input channel of the program	
Service name	Display service name. It is analyzed from the program source and can be modified.	
State	<p>Display the status of the program, green: normal; red: interruption; yellow: PSI change;</p> <p>Program playback conditions are different in different states. When green and yellow, the program plays normally.</p> <p>When turns red, the program plays abnormally.</p>	
CA	<p>CA certification, an electronic certification service, is used to check whether the program stream is encrypted.</p> <p>Unlocked means the program stream is not encrypted, locked means the program stream is encrypted.</p>	
RF channel	Allocate RF channels to programs according to actual conditions.	
PID Edit	Edit program information, which will be explained in detail below.	
Forward	When clicked it, will turn into a cancel button, allowing you to cancel	

the forwarding.

RF1 (474.000MHz)
8.15/48.20Mbps
17%

RF2 (482.000MHz)
8.46/48.20Mbps
18%

RF3 (490.000MHz)
0.01/48.20Mbps
0%

RF4 (498.000MHz)
0.01/48.20Mbps
0%

RF5 (506.000MHz)
0.01/48.20Mbps
0%

RF6 (514.000MHz)
0.01/48.20Mbps
0%

RF7 (522.000MHz)
0.01/48.20Mbps
0%

RF8 (530.000MHz)
0.01/48.20Mbps
0%

Cancel Forwarding

Quick Setting

Show

All

RF Channel

All

NO.	Type	Slot	Service Name	State	CA	RF Channel	PID Edit	Action
IP ETH1 239.1.1.143:50000 (0/1)								
1	IP	0-1	CCTV-5			Select a channel		Forward
IP ETH1 239.1.1.144:50000 (1/1)								
IP ETH1 239.1.1.145:50000 (1/1)								
1	IP	0-3	Soccer			RF1 (474.000)MHz		Cancel
IP ETH1 239.1.1.146:50000 (0/1)								

Total 4 data

100 Data/Page

←

→

1

2

3

4

Total programs: 4

Forwarded programs: 2

Not forwarded programs: 2

Edit (Slot: 0-3)

Program Information

Destination PID

Service Number:

1

Service Name:

Soccer

Service Provider:

Soccer

LCN (D):

1

Source PID

Service Number:

1

Service Name:

Soccer

Service Provider:

Soccer

NO.	SRC PID	Type	DEST PID	TS Type	Enable
1	256	PMT PID	32		
2	257	PCR PID	33		
3	257	AVC(H264)	33	1B hex	✓
4	258	Mpeg-2 AAC	34	F hex	✓

Cancel

Submit

Detailed explanation of editing program information

Destinatio

Service

Fill in according to actual needs, the value range is:

n PID	number	1-65535. The content shown in gray below is the target program number analyzed in the program source.
	Service name	Fill in the actual value, the value range is: 32 bytes. The content shown in gray below is the name of the target program analyzed in the program source.
	Service provider	It is analyzed from the program source and does not need to be changed. The value range is: 32 bytes.
Source PID	Service number	Comment the source target number and prompt the user for the value of the source target number.
	Service name	Annotate the source program name and prompt the user for the value of the source program name.
	Service provider	Annotate source program name, prompt user service provider value
Detailed explanation of the table below the pop-up window		
NO.		List serial number
SRC. PID		Each media data stream has a unique PID that identifies the source and type of media packets
Type		The type of genre is determined by the content contained in the program source, and there may be more genres
Type	PMT PID	Each program has a unique PMT PID that identifies the program's PMT.

	PCR PID	Each program needs an independent PCR PID to synchronize the audio and video streams of the program.
	AVC(H264)	Video compression standards
Dest PID	It is based on analysis of program source data and does not need to be changed.	
TS type	It is based on analysis of program source data and does not need to be changed.	
Enable	It can be controlled to open or close. It will not take effect after it is closed.	
Submit	After the modified content is submitted successfully, it will take effect.	
Cancel	Close editing page	

<div> Cancel Forwarding Quick Setting Show All RF Channel All </div>									
NO.	Type	Slot	Service Name	State	CA	RF Channel	PID Edit	Action	
IP ETH1 239.1.1.143:50000 (0/1)									
1	IP	0-1	CCTV-5			Select a channel		Forward	
IP ETH1 239.1.1.144:50000 (1/1)									
IP ETH1 239.1.1.145:50000 (1/1)									
1	IP	0-3	Soccer			RF1 (474.000)MHz		Cancel	
IP ETH1 239.1.1.146:50000 (0/1)									
Total 4 data 100 Data/Page << 1 >>									
Total programs: 4 Forwarded programs: 2 Not forwarded programs: 2									

Setting ✕

Timeout Setting

s

Range: 5 ~ 120s

CA Filtering

☐

PID Mapping

☒

Cancel

Submit

Setting	
Timeout setting	Set the time to analyze the program, and stop the analysis after timeout. Value range: 5-120s
CA Filtering	After turning it on, you can filter the encrypted EMM information of satellite programs.
PID Mapping	Open by default. In order to prevent two programs from having the same target PID

5.6. Output

Output management mainly manages output programs and sets the output frequency, modulation format, etc. of the program.

The screenshot shows the SOUKA web interface for channel management. The 'Channel List' tab is selected, showing a table of RF channels. The table includes columns for channel number, source, RF channel, service number, service name, and LCN (ID). Two channels are configured: RF 1 (474.000 MHz) for Soccer and RF 2 (482.000 MHz) for MTV. The interface also includes a 'Show' dropdown, 'Delete' and 'Submit' buttons, and a pagination bar at the bottom.

NO.	Source	RF Channel	Service Number	Service Name	Service Number	Service Name	LCN (ID)	Action
1	IP(0-3)	RF1 (474.000MHz)	1	Soccer	1	Soccer	1	[Edit] [Delete]
1	IP(0-2)	RF2 (482.000MHz)	1	MTV	33	MTV	1	[Edit] [Delete]
RF 3 (490.000 MHz)								
RF 4 (498.000 MHz)								
RF 5 (506.000 MHz)								
RF 6 (514.000 MHz)								
RF 7 (522.000 MHz)								
RF 8 (530.000 MHz)								

5.6.1. Channel list

The screenshot shows the SOUKA web interface for channel management. The 'Channel List' tab is selected, showing a table of RF channels. The table includes columns for channel number, source, RF channel, service number, service name, and LCN (ID). Two channels are configured: RF 1 (474.000 MHz) for Soccer and RF 2 (482.000 MHz) for MTV. The interface also includes a 'Show' dropdown, 'Delete' and 'Submit' buttons, and a pagination bar at the bottom.

NO.	Source	RF Channel	Service Number	Service Name	Service Number	Service Name	LCN (ID)	Action
1	IP(0-3)	RF1 (474.000MHz)	1	Soccer	1	Soccer	1	[Edit] [Delete]
1	IP(0-2)	RF2 (482.000MHz)	1	MTV	33	MTV	1	[Edit] [Delete]
RF 3 (490.000 MHz)								
RF 4 (498.000 MHz)								
RF 5 (506.000 MHz)								
RF 6 (514.000 MHz)								
RF 7 (522.000 MHz)								
RF 8 (530.000 MHz)								

Source

Filter the signal source of the program according to the type of signal

	source.
Delete	After checking the programs that need to be deleted, click Delete. After deletion, the programs will become unforwarded, and the status of these programs in routing management will become unforwarded.
Submit	Modification of the information in the form will only take effect after successful submission.

Note: The remaining parameter settings are consistent with those in routing management.

5.6.2. RF settings

The screenshot shows the SOUKA RF Settings interface. At the top, there's a 'Channel List' button and a highlighted 'RF Settings' button. Below this, the 'Modulation' section is set to 'DVB-T2'. A notice says: 'Notice: Please click the Submit button to activate the new modulation.' The 'PLP' section includes fields for 'Fec Block Length' (16200), 'PLP Constellation' (QAM256), 'Rate Code' (5/6), 'CONSTELLATION ROTATION' (checked), 'INPUT TS HEM' (checked), and 'TIME INTERVAL' (unchecked). The 'RF Settings' section contains a table with columns: NO., RF Channel, RF Enable, Frequency(MHz), TSID, ONID, Network ID, Network Name, PSI/SI, and Attenuation (-dB). The table has two rows: 'Module: 1' and 'Module: 2'. A 'Submit' button is located at the bottom right.

Set the 8 output channels in the RF settings. There are 2 modules, each module has 4 RF frequencies.

Note: Modified data must be submitted successfully to take effect.


RF Settings

NO.	RF Channel	RF Enable	Frequency(MHz)	TSID	ONID	Network ID	Network Name	PSI/SI	Attenuation (- dB)
Module: 1									
1	1	<input checked="" type="checkbox"/>	<input type="text" value="474.000"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="DTV"/>	<input type="button" value="⬇"/>	<div><div></div><div>0.0</div></div>
2	2	<input checked="" type="checkbox"/>	<input type="text" value="482.000"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="DTV"/>	<input type="button" value="⬇"/>	
3	3	<input checked="" type="checkbox"/>	<input type="text" value="490.000"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="DTV"/>	<input type="button" value="⬇"/>	
4	4	<input checked="" type="checkbox"/>	<input type="text" value="498.000"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="DTV"/>	<input type="button" value="⬇"/>	
Module: 2									
1	5	<input checked="" type="checkbox"/>	<input type="text" value="506.000"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="DTV"/>	<input type="button" value="⬇"/>	<div><div></div><div>0.0</div></div>
2	6	<input checked="" type="checkbox"/>	<input type="text" value="514.000"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="DTV"/>	<input type="button" value="⬇"/>	
3	7	<input checked="" type="checkbox"/>	<input type="text" value="522.000"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="DTV"/>	<input type="button" value="⬇"/>	
4	8	<input checked="" type="checkbox"/>	<input type="text" value="530.000"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="DTV"/>	<input type="button" value="⬇"/>	

Submit

PSI/SI

PAT: ☒ PMT: ☒ SDT: ☒ NIT: ☒ CAT: ☒ TDT: ☒ TOT: ☒ MGT: ☒ CVCT: ☒



Cancel

Submit


NO.	Display the serial number of the RF channel number to visually display the number of RF channels	
RF channels	Display the numbers of different channels in the module	
RF enable	Enabled by default. When closed, the output channel is closed	
Frequency	Unit: MHz Set according to actual needs. Value range: 50-999.999	
TSID	Set according to actual needs. Value range: 1-65535	
ONID	Set according to actual needs. Value range: 0-65535	
Network ID	Set according to actual needs. Value range: 0-65535	
Network name	Fill in the network name according to actual needs. Value range: 32 bytes	
PSI/SI	PAT	Program association table. Associating the program number with the program mapping table PID is the beginning of data acquisition;
	PMT	Program mapping table, specifying the PID of one or more programs;
	SDT	Business description table, describing various program and service information in the transmitted digital television signal
	NIT	The network information table describes the entire network, such as the number of TS streams, frequency points, modulation methods, etc.
	CAT	A conditional access table that associates one or more

		dedicated EMM flows with a unique PID;
	TDT	Time and date table. TDT is one of the various service information (SI) tables contained in the MPEG-2 transport stream. It is the abbreviation of time and date table and is used to update the internal clock of the IRD.
	TOT	Time offset table. gives information about the current time, date, and local time offset

	MGT	Main wizard table. Master Wizard Table (MGT) is like an index to all other PSIP tables
	CVCT	Cable virtual channel list.
Attenuation	Adjust when the TV signal is poor, 0 is the default value. The setting range is 0-20, in steps of 0.5, and the maximum value can only be changed to 20.	
Submit	Modifying the data in the form will take effect only after successful submission.	

5.7. System

Able to set device name, network/IP input network port settings, password settings, system configuration, time settings and cloud network management binding.



5.7.1. Basic parameters

Modify the device name, click Submit, and the name in the upper left corner will also be changed. A maximum of 32 bytes can be entered.

Basic Parameters

Network

Account

System

Time And Date

CLOUD

Basic Parameters

Device Name: SKD710A

Submit

5.7.2. Network

Network setting	
NMS	Network management port, connected computers must be in the same network segment.
ETH1	Network port 1, fill in according to actual needs.

IGMP version: IGMPv1 defines the basic group member query and reporting process. IGMPv2 adds a mechanism for inquire election and group member departure on this basis. The main function added in IGMPv3 is that members can specify to receive or not to receive certain Packets from the multicast source.

5.7.3. Account

Reset a new username and password.


Operation steps: First fill in the username and password in the Current User Information, and then fill in the new username and password. Only when the initial

username and password are entered correctly can the password be modified.

The screenshot displays the SOUKA web interface's 'Account' configuration page. The top navigation bar includes tabs for 'Basic Parameters', 'Network', 'Account' (which is the active tab), 'System', 'Time And Date', and 'CLOUD'. The main content area is divided into two sections: 'Current User Information' and 'New User Information'. The 'Current User Information' section features two input fields labeled 'Current Username' and 'Current Password'. The 'New User Information' section features three input fields labeled 'New Username', 'New Password', and 'Confirm Password'. A blue 'Submit' button is positioned at the bottom of the form.

5.7.4. System

In the system configuration, follow the operating instructions to upgrade the system, restore the factory, restart, export the system configuration file, and import the system configuration file. The import and export files can manually back up the system configuration information. When you need to restore the previous configuration information, import the corresponding configuration file.




The screenshot shows the 'System' tab in the SOUKA web interface. It contains five sections: 'Upgrade System from file', 'Restore to factory settings', 'Reboot', 'Export Settings', and 'Import Settings'. Each section has a brief instruction and a corresponding button.

- Upgrade System from file:** Click the Browse button below and import the upgrade file, then click the Upgrade button to upgrade the system. The device will automatically restart, after the upgrade is completed. Buttons: Browse, Upgrade.
- Restore to factory settings:** Click the Restore button to reset the device to the Factory defaults. The device will automatically reboot, when the restore is completed. Button: Restore.
- Reboot:** Click the Reboot button to reboot the device. Button: Reboot.
- Export Settings:** Click the Export button, then the device will back up all the current settings into your computer. Button: Export.
- Import Settings:** Click the Browse button below and load the configuration file, then click the import button to apply the file. The device will automatically reboot, when the restore is completed. Buttons: Browse, Import.

5.7.5. Time And Date

It can automatically calibrate time information, or manually set the time and adjust the time zone according to actual needs.



The screenshot shows the 'Time And Date' tab in the SOUKA web interface. It contains a form with three fields: 'Enable NTP' (checkbox), 'Time And Date' (text input), and 'Local Timezone' (dropdown menu). A 'Submit' button is at the bottom.

Time And Date

Enable NTP: ☐

Time And Date: 2000-05-02 01:10:44

Local Timezone: (UTC-0:00) Coordinated U ▼

Submit

5.7.6. COULD

Please enter the cloud network management system account to bind the device. If

you do not have an account, please register an account in the cloud network management system.

Enter the cloud network management account and password to bind. After the binding is successful, the binding status light turns green.

CLOUD Enable	Cloud network management is enabled, checked by default. After unchecking, the device will be disconnected from the cloud network management.
Alarm Enable	Checked by default, device alarm information can be detected on the cloud network management.
Server Address	Fill in the server domain name of the cloud network management, default: iptv.soukacatv.com.cn
Server port	Fill in the server port of the cloud network management, the default is 7830
Binding status	Green: Binding successful; Gray: Unbound
Username	User name registered on the cloud network management system

Password	Password registered on the cloud network management system
----------	--

6. Equipment operation precautions

The company's product quality assurance system includes equipment testing and operating procedure inspections to ensure the reliability of product quality. The company has taken all possible measures before the product leaves the factory. The optical, electrical and mechanical indicators of the products all meet national standards. During use, in order to prevent possible potential problems, the following precautions should be strictly followed for relevant operations

6.1. Precautions

1. Place the device at an ambient temperature of 0~45°C. Other conditions meet the required scope of work.
2. Make sure the rear panel radiator is well ventilated and make sure all jacks are not blocked
3. Check whether the power supply voltage is within the specified range and whether all connections are correct
4. Check whether the adjustment level (dB) change is within its allowable range
5. Check whether the connection of each signal line is loose.
6. Please do not switch machines frequently (the switching interval should be at least 10 seconds)

6.2.The chassis needs to be unplugged from the power supply

1. The power cord or socket is damaged
2. If there is liquid injection equipment
3. Any debris falls into the chassis hole, causing an internal short circuit
4. Use water or soak
5. Collision or internal damage
6. Do not use this machine for a long time
7. If the preset is restored and the power is turned on, the device still does not work properly
8. Equipment needs maintenance

6.3.Common malfunctions

- ① No signal: Please check whether the modulation standard of the device is consistent with the receiving standard.
- ②Missing program: Please check whether there is a channel conflict, whether the video signal input is normal, and restart the device.

These terms are subject to change without prior notice, and we reserve the right of final interpretation. If you have any further questions, please contact our sales department directly.