



SKD7150P User Manual

DVB-S/S2 with CI Slot Input to IP Output IP Gateway



Dingshengwei Electronics Co., Ltd.

The final interpretation right of this document belongs to our company

Preface

Thank you for choosing our product.

This manual details the performance, installation and operation of the product. Please read this manual before use.

Our company, Ding Sheng Wei Electronics Co., Ltd., does not assume any responsibility for any losses caused by violation of safety regulations.

1. Incoming inspection

- (1) Open the equipment box and check the contents against the product packing list.
- (2) If the packing list does not match the actual item, please contact us.

2. Read the instruction manual

Please read the instructions and follow all instructions.

(1) Power

The power supply used with this device must comply with the indicated power supply and be grounded. When not using the machine for a long time, please unplug the power cord.

(2) Working environment

Keep the equipment working in a ventilated and dry place. Avoid excessive heat, moisture, dust and heat.

(3) Equipment cleaning

Before cleaning the device, unplug the power cord. Do not use liquid or spray cleaners.

(4) Power cable protection

Pay special attention to the safety protection of plugs, sockets and power cords

(5) Overload

Be careful not to overload the power supply at the outlet. Use caution when using extension cords or integrated sockets as this may result in electric shock and fire.

(6) Lightning

To prevent damage caused by lightning, please use this device in a lightning protection device, which can effectively prevent damage caused by lightning or power grid fluctuations.

(7) Foreign matter or liquid intrusion

Do not insert foreign objects into the machine or spill any liquid into the machine.

(8) Attachments

Do not use accessories not recommended by the manufacturer, as this may cause danger

(9) Transportation

When transporting the machine, the original packaging of the product should be used to avoid damage. Do not place heavy objects on the machine or step on it. Otherwise, personal injury may occur and the machine may be damaged.

(10) Maintenance

Do not open the box and repair by yourself to avoid personal injury or serious damage to the machine.

During the warranty period, if the product is damaged due to natural causes and is disassembled without authorization, free warranty will not be provided.

Concent

1. Product description	1
1.1. Picture	1
1.1.1. SKD7150P parameter	2
1.2. Features	2
1.3. Application scenarios	3
2. Structure diagram	3
2.1. SKD7150P	3
2.2. Rear panel	4
3. Installation guide	5
3.1. Installation preparation	5
3.2. Equipment installation process	5
3.3. Environmental conditions requirements	5
3.4. Grounding requirements	6
3.4.1. Cabinet grounding	7
4. Built-in web management terminal operation	7
4.1. Preparation before operation	7
4.2. Login interface	7
4.3. Device status	9
4.4. Input management	10
4.5. Router management	13
4.6. Output management	19
4.7. System	19
4.7.1. Network setting	20
4.7.2. Password setting	20
4.7.3. System parameters	21
4.7.4. Time setting	21
4.7.5. Cloud network management binding	22
5. Equipment operation precautions	23
5.1. Precautions	23
5.2. The chassis needs to be unplugged from the power supply	24

5.3. Common malfunctions 24

1. Product description

SKD7150P is a platform product for centralized processing of small IP TV front-end services.

The installation method is flexible and can be installed in cabinet, wall-mounted or desktop. Device parameters can be configured through local or cloud network operation. The WEB page is beautiful and easy to understand, and the operation is simple. It has intelligent functions such as batch import and export of parameters and exception reminders. It is a highly integrated and cost-effective IP TV front-end signal comprehensive processing equipment.

1.1. Picture

Frontal panel



Rear panel



1.1.1. SKD7150P parameter

SKD7150P Host performance parameters		
Size	318(L)*260(W)*44(H)mm	
Installation form	1U 19 inch chassis, Support Desktop, Rack-mounted and wall-mounted.	
Working temperature, humidity	-10°C-45°C、40%-70%	
Storage temperature and humidity	-40°C-70°C、40%-95%	
Power parameters	Supply voltage	DC12V
	Maximum current	7000mA
DVB-S/S2 with CI Slot input module parameter	Total number of slots	2
	Each slot can support 2 CI Slot	2 CAM slots
IP output parameter	IP output conector	1 Gigabit RJ45 network port
	Output format	Supports UDP/RTP protocol output, supports SPTS/MPTS stream processing, output IP Stream in MPTS with 4 IP Address or SPTS with 256 IP address

1.2. Features

- A single device supports up to 2 input modules.
- Supports 2 or 4 DVBS-S2 input with CI Slot, independent PCMCIA card decryption

- Supports PID remapping, PSI/SI information editing and insertion
- Supports optional MPTS or SPTS output. For MPTS, the maximum supported is 4 IP addresses; for SPTS, the maximum supported is 256 IP addresses.
- 1 Gigabit port and 1 management port
- Operated through PC (WEB), the device supports cloud management

1.3. Application scenarios

- Business travel hotel
- Clubhouse
- Hospital
- Baths
- School
- Leisure and entertainment clubs
- Prison

2. Structure diagram

2.1. SKD7150P



Number	Function	
1	PER	This indicator light lights up when the device is powered on
	RUN	This indicator light lights up when the device is running
2	CH1	When the No. 1 port receive the signal, the indicator light lights up.

	CH2	When the No. 2 port receive the signal, the indicator light lights up.
	CH5	When the No. 5 port receive the signal, the indicator light lights up.
	CH6	When the No. 6 port receive the signal, the indicator light lights up.
3	DATA OUT	Gigabit output network port
4	NMS	Management
5	DFAULT	Restore factory settings button. If you need to restore factory settings, you need to press and hold for 15 seconds.

2.2. Rear panel



Number	Function	
1	RF1	Signal access interface, the corresponding PCMICA card needs to be inserted
	RF2	Signal access interface, the corresponding PCMICA card needs to be inserted
2	RF1	Signal access interface, the corresponding PCMICA card needs to be inserted
	RF2	Signal access interface, the corresponding PCMICA card needs to be inserted
3	Switch	
4	Ground	
5	Power inlet	

3. Installation guide

3.1. Installation preparation

When installing the device, follow these steps:

- Check for possible loss or damage of equipment during transportation;
- Prepare a suitable environment for installation;
- Install the required input and output cables;

Each detail of the equipment installation is described in the remainder of this chapter, using the rear panel diagram as a reference for specific locations.

3.2. Equipment installation process

Step 1:Unpacking and inspecting goods

Step 2:Fixed equipment

Step 3:Connect power and ground wires

Step 4:Connect signal cable

Step 5:Set device parameters

Step 6:Equipment operation

3.3. Environmental conditions requirements

Project	Requirement
Control room space	When installing multiple rows of cabinets, the distance between the front and rear doors of the cabinet is 1.2~1.5m and the distance from the wall is 0.8m.

Control room floor	Non-conductive and dust-free. The volume resistivity of the ground anti-static material is $1 \times 10^7 \sim 1 \times 10^{10}$, and the grounding current limiting resistance is 1M. The floor load-bearing should be greater than 450Kg/m ² .
Ambient temperature	For long-term work in an environment of 5~40°C, and for short-term work in an environment of 0~45°C, it is best to install air conditioners in places to facilitate heat dissipation.
Relative humidity	Work long-term in the 20% to 95% environment and short-term in the 10% to 97% environment.
Ambient air pressure	86kPa~106kPa.
Windows	Dust-proof rubber strips must be added for sealing. It is recommended that windows be installed with double-glazing and strictly sealed.
Wall	Wallpaper can be applied or matte paint can be applied, but paint that is easily powdered should not be applied.
Fire protection requirements	The control room should be equipped with an automatic fire alarm system and a portable fixed fire extinguishing system.
Power requirements	Three independent power supply systems are required for equipment power supply, air conditioning power supply, and lighting power supply. The equipment is powered by AC power supply. The AC power supply adopts 220V \pm 20% 50/60Hz. Please check carefully before operating the equipment.

3.4. Grounding requirements

- The good ground wire design of each functional module is the basis for the stable and reliable operation of the whole machine, and is the primary guarantee for lightning protection and anti-interference. Therefore, system grounding must follow the following principles;
- The ground conductor must use copper conductor to reduce high-frequency impedance, and the ground wire should be as thick and short as possible;

- The connection points at both ends of the grounding wire should be confirmed to have good electrical contact and should be treated with anti-corrosion treatment;
- It is strictly prohibited to use other equipment as part of the electrical connection of the ground wire;
- The cross-sectional area of the ground wire connecting the cabinet to the lightning protection unit must be greater than or equal to 25mm².

3.4.1. Cabinet grounding

The ground terminals of each cabinet in the same computer room should be connected to the protective ground copper bar provided by the control room. The grounding wire is required to be as short as possible. If the wiring is too long during project installation, it should be cut off to avoid coiling of the grounding wire. The cross-sectional area of the conductor from the ground terminal to the ground bar must be greater than or equal to 25mm².

4. Built-in web management terminal operation

4.1. Preparation before operation


- The NMS network port of the device is connected to the PC network port;
- Power the equipment;

4.2. Login interface

- You can check the IP address of the device through the operation panel.
- Open IE browser/Firefox browser/Google Chrome/Opera browser/Maxthon browser, enter the device IP address in the address bar (generally default: 192.168.1.30),

and after confirmation, the login interface will be displayed as follows:


- Enter username and password, the default is: user
- Click to log in



Notice:

1. If the connection cannot be made, please check whether the PC and the device are on the same network segment. If not, please add a new network segment in the advanced TCP/IP settings of the PC. For example: the PC's IP address is 192.168.99.252, which can be changed to 192.168.1.xxx (xxx can be any value from "1" to "254" except "252" to avoid IP conflicts).
2. If you still cannot connect after the above operations, or you forgot to log in to the IP address, please operate the front panel of the device to restore the factory default values.
3. If you need to change the language, please change it in the upper right corner of the page. Select ENGLISH/简体中文.

4.3. Device status



Serial ID	Display device serial number
Software version	Display the current software version number of the device
Temperature	Display the temperature of the device's core board, and display the number of temperature progress bars based on the number of core boards.
Rear panel	Display the current access status of the rear panel. Green: connected; gray: not connected
Cooling Fans	Display the operating status of the fans in the device. Under normal conditions, all fans will rotate. Blue: running; black: stopped; the fan stops running and a yellow triangle warning appears△
Front panel	Displays the current access status of the front panel. Green: connected; gray: not connected
Language settings	简体中文/ENGLISH
User name	Display the user name currently logged in to the device backend
Quit	Exit the device background management terminal
Cloud network management	Displays the binding status of the device on souka cloud. Green: bound; gray: unbound


binding status


4.4. Input management

NO.	State	Slot	Strength	Quality	Offset(MHz)	PER	Bitrate(Kbps)	LNB FREQ. (MHz)	SAT FREQ. (MHz)	Symbol Rate(KHz)	LNB Control	22KHz	DiSeqC	CI Setting	CI State	Analysis
1	Green	1-1	88%	19%	-0.001	0.000	58962.00	5150	4120	30000	13'	OF	OF			Apply
2	Green	1-2	91%	22%	-0.000	0.000	44007.00	11300	12330	27500	13'	OF	OF			Apply
3	Gray	2-1	0%	0%	0.000	0.000	0.00	5150	4180	30000	OF	OF	OF			Apply
4	Gray	2-2	0%	0%	0.000	0.000	0.00	5150	4180	30000	OF	OF	OF			Apply

No.	Display the serial number of the channel number to visually display the number of channels
State	Display the signal status of the channel. <ul style="list-style-type: none"> • Gray: Not connected; • Orange: signal locked; • Green: The signal is locked and analyzed successfully;
Slot	Display the card and corresponding channel number. For example: 1-1 represents the first channel of card 1.
Strength	Displays the signal strength of each channel, the higher the signal strength, the better
Quality	Displays the signal quality of each channel. Orange indicates poor signal quality. The higher the signal quality, the better.
Offset (MHz)	Display the signal frequency offset value of each channel
PER	Displays the bit errors of the signal for each channel
Bitrate (Kbps)	Display the code rate of the signal of each channel


LNB FREQ.(MHz)	The value range is 0-100000. Fill in according to the label of the tuner. The outdoor unit of the satellite radio and television receiving system is composed of receiving antenna, feed source, tuner and transmission feeder. The tuner is the most front-end equipment in the entire satellite radio and television receiving system.
SAT FREQ.(KHZz)	Parameters of accepted satellites. First, you need to determine the position of the tuner, confirm the parameter information of the aligned satellite, and then fill in the accurate values according to the satellite reference table provided by the merchant, or check the satellite reference table online. The value range is 0-100000.
Symbol rate(KHZz)	Parameters of accepted satellites. First, you need to determine the position of the tuner, confirm the parameter information of the aligned satellite, and then fill in the accurate values according to the satellite reference table provided by the merchant, or check the satellite reference table online, and match it with the downlink frequency. Scope of value: 1000-45000
LNB control	Feedback selection, 13V, 18V or OFF. The different purpose of the 13V and 18V voltage levels is to choose the polarization method of the high-frequency head of the satellite pot. The corresponding signal radiation methods of the polarization method are different, and the signal strength is different. Normal 13V corresponds to vertical polarization; 18V corresponds to the 18V horizontal polarization method. In the actual situation, we don't know how long the user's coaxial axis is, so the output voltage needs to be changed, which can compensate the effect of the long coaxial axis
22KHz	You can select ON or OFF. ON means that the satellite signal flows through the 22K port line. After the 22K switch receives this pulse signal, it gets a DC voltage after rectification by the internal rectification circuit of the 22K switch to drive the 22K switch from normally closed

	end conduction to normally open end conduction to achieve the purpose of switching. The function of the 22k switch is to switch.		
DiSEqC	Optional A, B, C, D or off		
CI setting		Card speed	Range: 24-108Mbit/s
		PID Usage	Range: 4-256
		TS delay	Range: 5-205
		Stream bypass	Whether to check, the data flow after checking is not through the smart card
		Error recovery	Whether to check, after checking, the smart card will automatically reboot when the bit rate and other abnormalities occur.
CI states		CAM reset	Click the reset button to reset the set data
		CAM inserted	Inserted/No
		CAM Initial State	Success/Failed
		CAM Name	SMIT, smart card's name
		CAM SystemID	4A02/4A0E, smart card ID
		System Input Bitrate (kbps)	Display the input code rate of the system
		CAM Input Bitrate (kbps)	Display the input bit rate of the smart card

		CAM Output Bitrate (kbps)	Display the output bit rate of the smart card
		Smart information	Display data from smart card
		Status information	The times of restarts of smart cards
Analysis	After clicking the Apply button, the signal of the channel is analyzed.		

4.5. Router management

In routing management, we can analyze and forward programs.



Check	<p>You need to click the + sign first to expand the program before you can select the program.</p> <p>The all-select check box can only select all expanded programs. Programs that have not been expanded by pressing the plus sign cannot be selected.</p>
Cancel	First check, then click the Cancel Forward button to cancel forwarding the

	program
No.	Represents: signal source subcard-channel (number of forwarded programs/total number of programs) Click the "+" sign to expand and display the program list under the channel. The programs can be set, analyzed and forwarded; Click the "-" sign to close the program list;
Type	Display the input type of this program
Slot	Display the input channel of the program
Service name	Display service name. It is analyzed from the program source and can be modified.
State	Display the status of the program, green: normal; red: interruption; yellow: PSI change; Program playback conditions are different in different states. When green and yellow, the program plays normally. When red, the program plays abnormally.
Dest.IP	Display the IP address information of the program
Edit	Edit program information, which will be explained in detail below.
Forward	Forwarding a program, when clicked, it will turn into a cancel button, allowing you to cancel the forwarding.

NO.	Type	Slot	Service Name	State	Output Type	Unicast	Dest. IP	Dest. Port	Edit	Action
<div> <div>DVB/S2(CAM) 1-1 (8/18)</div> <div>CAM Usage: 0.122/72Mbit/s</div> <div>STPS</div> </div>										
1	DVB/S2(CAM)	1-1	My_Shop_R				239.1.1.100	50000		Cancel
2	DVB/S2(CAM)	1-1	Kuru(Rak Tae Kaset TV)				239.1.1.101	50000		Cancel
3	DVB/S2(CAM)	1-1	True50 - R				239.1.1.102	50000		Forward
4	DVB/S2(CAM)	1-1	TVD 2				239.1.1.103	50000		Cancel
5	DVB/S2(CAM)	1-1	TopNew_77				239.1.1.104	50000		Forward
6	DVB/S2(CAM)	1-1	GOOD LUCK TV_R				239.1.1.105	50000		Forward
7	DVB/S2(CAM)	1-1	TIGER_FHD				239.1.1.106	50000		Cancel
8	DVB/S2(CAM)	1-1	SHOP_HD				239.1.1.107	50000		Forward

| Edit (Slot: 1-1)



| Program Information

Destination PID

Service Number: 707

Service Name: True50 - R

Service Provider:

NO.	SRC PID	Type	TS Type
1	207	PMT PID	
2	307	PCR PID	
3	307	AVC(H264)	1B hex
4	407	Mpeg-2 AAC	F hex

Cancel

Submit

Program information		
Destination PID	Service number	Fill in according to actual needs, the value range is: 1-65535. The content shown in gray below is the target program number analyzed in the program source.
	Service name	Fill in the actual value, the value range is: 32 bytes. The content shown in gray below is the name of the target program analyzed in the program source.
	Service Provider	It is analyzed from the program source and does not need to be changed. The value range is: 32 bytes.
SRC PID	Service number	Comment the source service number and prompt the user

		for the value of the source service number.
	Service name	Annotate the source service name and prompt the user for the value of the source service name.
	Service provider	Annotate source service name, prompt user service provider value.

Detailed explanation of editing program information

NO.		List serial number
SRC PID		Each media data stream has a unique PID that identifies the source and type of media packets
Type		The type of genre is determined by the content contained in the program source, and there may be more genres
Type	PMT PID	Each program has a unique PMT PID that identifies the program's PMT.
	PCR PID	Each program needs an independent PCR PID to synchronize the audio and video streams of the program.

Settings button

AVC(H264)	Video compression standards
Mpeg-1 Audio	Digital audio compression format
Dest.PID	Based on analysis of program source data and does not need to be changed.
Stream type	Based on analysis of program source data and does not need to be changed.
Enable	It can be controlled to open or close. It will not take effect after it is closed.
Submit	After the modified content is submitted successfully, it will take effect.
Cancel	Close editing page

The screenshot shows the SOUKA web interface. The top navigation bar includes the SOUKA logo, language selection (ENGLISH), user profile, and a quit button. The left sidebar contains navigation links: Status, Input, Router (selected), Output, and System. The main content area is titled 'General Settings' and displays a table of service settings. The table has columns: NO., Type, Slot, Service Name, State, Output Type, Unicast, Dest. IP, Dest. Port, Edit, and Action. There are 5 rows of service data. The first row is highlighted. The Action column contains icons for settings, edit, and delete. The settings icon is highlighted with a red box.

NO.	Type	Slot	Service Name	State	Output Type	Unicast	Dest. IP	Dest. Port	Edit	Action
1	DVBS/S2(CAM) 1-1 (8/18)	CAM Usage: 0.122/72Mbit/s	My_Shop_R	●	STPS		239.1.1.100	50000		Settings
2	DVBS/S2(CAM)	1-1	Kuru(Rak Tae Kaset TV)	●			239.1.1.101	50000		Cancel
3	DVBS/S2(CAM)	1-1	True50 - R	●			239.1.1.102	50000		Forward
4	DVBS/S2(CAM)	1-1	TVD 2	●			239.1.1.103	50000		Cancel
5	DVBS/S2(CAM)	1-1	TopNew_77	●			239.1.1.104	50000		Forward

Setting

Output Type

STPS

STPS

BYPASS

Timeout in

Range: 5~120s

Cancel

Timeout	Set the time to analyze the channel, and stop the analysis after timeout. Value range: 5-120s
CA filter	After turning it on, you can filter the encrypted EMM information of satellite programs.
PID mapping	Open by default. In order to prevent two programs from having the same target PID

SOUKA

Status

Input

Router

Output

System

Show All

General Settings

NO.	Type	Slot	Service Name
DVBS/S2(CAM) 1-1 (8/18) CAM Usage: 0.12			
1	DVBS/S2(CAM)	1-1	My_Shop_R
2	DVBS/S2(CAM)	1-1	Kuru(Rak Tae Kaset TV)
3	DVBS/S2(CAM)	1-1	True50 - R
4	DVBS/S2(CAM)	1-1	TVD 2

DVBS/S2 signal source details	
PSI	PSI information consists of program association table PAT, program mapping table PMT and network information table SDT.
PAT	The program association table associates the program number with the program mapping table PID, which is the beginning of data acquisition;
PMT	Program mapping table, specifying the PID of one or more programs;
SDT	Describe various program and service information in the transmitted digital television signal

Analysis: Analyze the programs in the signal source. When not analyzed, the total number of black programs is 0.


In the SKD7150 module, each channel will display a CAM load progress bar, showing the CAM load of the channel.

The maximum value of the load is set in the read rate in the CI settings in the input management.

SOUKA										
<div> <div> Status Input Router Output System </div> <div> Show: All General Settings </div> </div>										
NO.	Type	Slot	Service Name	State	Output Type	Unicast	Dest. IP	Dest. Port	Edit	Action
DVBS/S2(CAM) 1-1 (8/18)			CAM Usage: 0.123/72Mbit/s		STPS					
1	DVBS/S2(CAM)	1-1	My_Shop_R	●		<input type="checkbox"/>	239.1.1.100	50000		Cancel
2	DVBS/S2(CAM)	1-1	Kurui(Rak Tae Kaset TV)	●		<input type="checkbox"/>	239.1.1.101	50000		Cancel
3	DVBS/S2(CAM)	1-1	True50 - R	●		<input type="checkbox"/>	239.1.1.102	50000		Forward
4	DVBS/S2(CAM)	1-1	TVD 2	●		<input type="checkbox"/>	239.1.1.103	50000		Cancel
5	DVBS/S2(CAM)	1-1	TopNew_77	●		<input type="checkbox"/>	239.1.1.104	50000		Forward
6	DVBS/S2(CAM)	1-1	GOOD LUCK TV_R	●		<input type="checkbox"/>	239.1.1.105	50000		Forward

4.6. Output management


Output management mainly manages output programs and exports program lists.



NO.	Dest. IP	Dest. Port	Service Number	Service Name	Service Provider
DVBS/S2(CAM) 1-1					
1	239.1.1.100	50000	704	My_Shop_R	
2	239.1.1.101	50000	705	Kuru(Rak Tae Kaset TV)	
3	239.1.1.103	50000	708	TVD 2	
4	239.1.1.106	50000	712	TIGER_FHD	
5	239.1.1.109	50000	715	UMMHD	
6	239.1.1.112	50000	718	BJ CHANNEL	
7	239.1.1.114	50000	720	MirrorHDR	
8	239.1.1.116	50000	725	CHOMYUT_HD	
DVBS/S2(CAM) 1-2					
1	239.1.2.100	50000	1	HD Phx InfoNews Channel	Phoenix Satellite Television Co Ltd

4.7. System

Able to set network and IP output network ports, password settings, system configuration, time settings and cloud network management binding.



SOUKA | ENGLISH | user | Quit

Basic Parameters | Network | Account | System Parameters | Time and Date | CLOUD

Basic Parameters

Device Name: SKD

Submit

4.7.1. Network setting

Network	
NMS	Network management port, connected computers must be in the same network segment.
ETH1	Network port 1, fill in according to actual needs.

IGMP version: IGMPv1 defines the basic group member query and reporting process. IGMPv2 adds a mechanism for querier election and group member departure on this basis. The main function added in IGMPv3 is that members can specify to receive or not to receive certain Packets from the multicast source.

4.7.2. Password setting

Reset a new username and password.

Operation steps: First fill in the username and password in the initial information, and then fill in the new username and password. Only when the initial username and password are entered correctly can the password be modified.

SOUKA | ENGLISH | user | Quit

Basic Parameters | Network | **Account** | System Parameters | Time and Date | CLOUD

Current User Information

Current Username

Current Password

New User Information

New Username

New Password

Confirm Password

4.7.3. System parameters

In the system configuration, follow the operating instructions to upgrade the system, restore the factory, restart, export the system configuration file, and import the system configuration file. The import and export files can manually back up the system configuration information. When you need to restore the previous configuration information, import The corresponding configuration file is enough.

SOUKA | ENGLISH | user | Quit

Basic Parameters | Network | Account | **System Parameters** | Time and Date | CLOUD

Upgrade System from file

Click the Browse button below and import the upgrade file, then click the Upgrade button to upgrade the system. The device will automatically restart,after the upgrade is completed.

Restore to factory settings

Click the Restore button to reset the device to the Factory defaults. The device will automatically reboot,when the restore is completed.

Reboot

Click the Reboot button to reboot the device.


Export Settings

Click the Export button,then the device will back up all the current settings into your computer.

4.7.4. Time setting


It can automatically calibrate time information, or manually set the time and adjust the time

zone according to actual needs.



4.7.5. Cloud network management binding

Please enter the cloud network management system account to bind the device. If you do not have an account, please register an account in the cloud network management system. Enter the cloud network management account and password to bind. After the binding is successful, the binding status light turns green.



Cloud Enable	Cloud network management is enabled, checked by default. After unchecking, the device will be disconnected from the cloud network management.
Alarm Enable	Checked by default, device alarm information can be detected on the

	cloud network management.
Server Address	Fill in the server domain name of the cloud network management, default: iptv.soukacatv.com.cn
Server Port	Fill in the server port of the cloud network management, the default is 7830
Binding Status	Green: Binding successful; Gray: Unbound
Username	User name registered on the cloud network management system
Password	Password registered on the cloud network management system

5. Equipment operation precautions

The company's product quality assurance system includes equipment testing and operating procedure inspections to ensure the reliability of product quality. The company has taken all possible measures before the product leaves the factory. The optical, electrical and mechanical indicators of the products all meet national standards. During use, in order to prevent possible potential problems, the following precautions should be strictly followed for relevant operations.

5.1. Precautions

1. Place the device at an ambient temperature of 0~45 ° C. Other conditions meet the required scope of work.
2. Make sure the rear panel radiator is well ventilated and make sure all jacks are not blocked
3. Check whether the power supply voltage is within the specified range and whether all connections are correct
4. Check whether the connection of each signal line is loose.
5. Please do not switch machines frequently (the switching interval should be at least 10 seconds)

5.2. The chassis needs to be unplugged from the power supply

1. The power cord or socket is damaged
2. If there is liquid injection equipment
3. Any debris falls into the chassis hole, causing an internal short circuit
4. Use water or soak
5. Collision or internal damage
6. Do not use this machine for a long time
7. If the preset is restored and the power is turned on, the device still does not work properly
8. Equipment needs maintenance

5.3. Common malfunctions

1. Missing program: Please check whether there is a channel conflict, whether the video signal input is normal, and restart the device.

These terms are subject to change without prior notice, and we reserve the right of final interpretation. If you have any further questions, please contact our sales department directly.